

TIMELESS ICON LIP STAIN

NEW

Cosphatec

700.140.2.1

LONG-LASTING COLOUR. WEIGHTLESS
FEEL.MOISTURISING.

Alternative preservation: Cosphaderm® Hexiol natural, Cosphaderm® Octiol natural

Phase	Ingredient	COSMOS	INCI	Supplier	%
A	Demin. Water		Aqua	-	85.15
A	Cosphaderm® Hexiol natural	✓	1,2-Hexanediol	Cosphatec GmbH	1.50
A	Cosphaderm® Octiol natural	✓	Caprylyl Glycol	Cosphatec GmbH	0.30
A	Sorbitol		Sorbitol	-	2.00
B	Glycerin		Glycerin	-	1.00
B	Cosphaderm® Propanediol natural palm free	✓	Propanediol	Cosphatec GmbH	3.00
B	Cosphaderm® Butiol natural	✓	Butylene Glycol	Cosphatec GmbH	5.00
B	Cosphaderm® X 34	✓	Xanthan Gum	Cosphatec GmbH	0.40
B	Pullulan		Pullulan	-	1.00
B	Cosphaderm® Sodium Hyaluronate high	✓	Sodium Hyaluronate	Cosphatec GmbH	0.10
B	Cosphaderm® Sodium Hyaluronate low	✓	Sodium Hyaluronate	Cosphatec GmbH	0.05
C	Unicert Red K7057_J		CI 17200	SENSIENT BEAUTY	0.10
C	FD&C Red 40 07700-C		CI 16035	SENSIENT BEAUTY	0.35
C	Unicert Red K7061-J		CI 45380	SENSIENT BEAUTY	0.05

MANUFACTURING PROCESS

Phase A: Combine all ingredients of phase A.

Phase B: Prepare phase B and slowly add to phase A under stirring. Continue stirring until everything is completely dissolved.

Phase C: Add phase C and stir until everything is homogeneous.

Adjust pH value to 5.50 ± 0.05 .

SPECIFICATION

Appearance: Clear, red, low viscous solution

pH: 5.5 ± 0.05

Stability: No separation after centrifugation (4000 rpm, 30 min), stable for 3 months at room temperature and 40 °C

Microbiological stability: proven

Disclaimer: This formulation proposal and our technical application advice are given to the best of our knowledge, but it is for information purposes only and no responsibility is assumed.