

ANTI-WRINKLE BASE

Cosphatec

100.39.1.1

PORE FILLING. LONG LASTING. FREE OF LISTED PRESERVATIVES.

Alternative preservation: Cosphaderm® POP, Cosphaderm® Propanediol natural

Phase	Ingredient	COSMOS	INCI	Supplier	%
A	Glycerin		Glycerin	Cremer GmbH	6.00
A	Natrosol® 250 HX		Hydroxyethylcellulose	-	1.00
A	Cosphaderm® Propanediol natural	✓	Propanediol	Cosphatec GmbH	4.00
A	Cosphaderm® Sodium Hyaluronate high	✓	Sodium Hyaluronate	Cosphatec GmbH	0.20
B	Demin. Water		Aqua	-	ad 100
C	Cosphaderm® POP		Propanediol, Caprylyl Glycol, Phenylpropanol	Cosphatec GmbH	1.00
C	Water-soluble Perfume		Parfum	Clariant AG	q.s.

Manufacturing Process

Phase A: Combine phase A and add demineralised water to phase A under stirring.

Phase B: Add water.

Phase C: Add Cosphaderm® POP and water-soluble perfume to phase A+B.

Adjust the pH to 5.5 ± 0.05 .

Specification

Appearance: Translucent gel

pH: 5.5 ± 0.05

Stability: Microbiological stability proven, no separation after centrifugation (4000 rpm, 30 min)