SKIN PERFECTING TONER

100.61.1.2

EXFOLIATING. PORE SIZE REDUCING. SOOTHING.



Alternative preservation: Cosphaderm® Pentiol natural, Cosphaderm® Propanediol natural

Phase	Ingredient	COSMOS	INCI	Supplier	%
A	Demin. Water		Aqua	-	90.90
Α	Cosphaderm® Propanediol natural	\checkmark	Propanediol	Cosphatec GmbH	4.00
Α	Cosphaderm® Pentiol natural	\checkmark	Pentylene Glycol	Cosphatec GmbH	3.00
Α	Cosphagard® SA natural	\checkmark	Salicylic Acid	Cosphatec GmbH	2.00
В	Cosphaderm® PA ECONAT	\checkmark	Phytic Acid, Aqua	Cosphatec GmbH	0.10

Manufacturing Process

Phase A: Combine all ingredients of phase A. Raise the pH to 11 to dissolve Cosphagard® SA natural completely.

Phase B: Add phase B and lower the pH to 4.0 ± 0.05 .

Specification

Appearance: Clear solution

pH: 4.0 ± 0.05

Stability: Microbiological stability proven, no separation after centrifugation (4000 rpm, 30 min)